



Product Manual



Contents

1	PREFACE	6
1.1	LEGAL INFORMATION	6
1.1.1	<i>Disclaimer.....</i>	<i>6</i>
1.2	PRESENTATION	6
1.3	TYPOGRAPHICAL CONVENTIONS	6
1.4	GENERAL AND SAFETY INFORMATION	6
1.4.1	<i>Safety symbols.....</i>	<i>6</i>
1.4.2	<i>General symbols</i>	<i>7</i>
1.4.3	<i>Minimum recommended profile for the BM operator and maintainer</i>	<i>7</i>
1.4.4	<i>Environmental and voltage conditions required for installation and operation</i>	<i>8</i>
1.4.5	<i>Instructions for testing and installation</i>	<i>9</i>
1.4.6	<i>Instructions for cleaning and decontamination</i>	<i>10</i>
1.4.7	<i>Instructions for inspection and maintenance</i>	<i>10</i>
1.5	CUSTOMER SERVICE	11
1.6	WARRANTY TERMS	12
2	INTRODUCTION	13
2.1	INTENDED USE.....	13
2.2	FEATURES.....	14
2.3	FUNCTIONS.....	14
2.4	INPUTS, OUTPUTS AND COMMUNICATION	14
2.4.1	<i>Inputs.....</i>	<i>14</i>
2.4.2	<i>Outputs.....</i>	<i>14</i>
2.4.3	<i>Communication</i>	<i>15</i>
3	DESIGN AND INSTALLATION	15
3.1	INSTALLATION AND REMOVAL OF TERMINALS	15
3.2	MECHANICAL INSTALLATION.....	15
3.2.1	<i>Standard DIN rail installation</i>	<i>15</i>
3.2.2	<i>Panel-mounted installation</i>	<i>17</i>
3.3	ELECTRICAL INSTALLATION	17
3.3.1	<i>Cable specification.....</i>	<i>19</i>
3.3.2	<i>Wiring diagram</i>	<i>20</i>
3.3.3	<i>Input terminals</i>	<i>20</i>
3.3.4	<i>Output terminals</i>	<i>21</i>
3.3.5	<i>Communication</i>	<i>21</i>
3.3.6	<i>Temperature sensor</i>	<i>22</i>
3.4	TAP ADAPTER	24
3.4.1	<i>Mechanical installation</i>	<i>24</i>
3.4.2	<i>Electrical installation</i>	<i>24</i>
3.4.3	<i>Layout of the TAP adapter socket terminals</i>	<i>25</i>
4	OPERATION	26
4.1	GENERAL INFORMATION ABOUT THE WEB INTERFACE	26
4.1.1	<i>Login.....</i>	<i>27</i>
4.1.2	<i>File transfer</i>	<i>27</i>
4.1.3	<i>About.....</i>	<i>27</i>
5	PARAMETERIZATION	28
5.1	INPUTTING AND VALIDATING PARAMETERS	28
5.2	ACQUISITION AND ANALYSIS	28



5.2.1	Sampling settings	28
5.2.2	Initial phase parameters	29
5.2.3	Adjustment parameters of the relevance curve	29
5.2.4	Self-diagnosis	30
5.2.5	PT100 sensor configuration	31
5.3	COMMUNICATION	32
5.3.1	Serial communication ports (RS485 - 'X')	32
5.3.2	Confirmation key	32
5.3.3	Network	33
5.4	SYSTEM AND CONTROL	35
5.4.1	Manually setting the date and time	35
5.4.2	Time zone	36
5.4.3	Mass log interval	36
5.5	ALARMS	36
5.5.1	Automatic mode activation	36
5.5.2	General settings	36
5.5.3	Percentages for automatic alarms	37
5.5.4	Alarm timing	38
5.5.5	Manual thresholds	38
5.5.6	Trend-based alarms	39
5.6	COMMANDS	40
5.6.1	Control and monitoring of banks	40
5.6.2	Maintenance and cleaning	40
5.6.3	Resetting trend calculations	40
5.6.4	Resetting communication settings	40
5.6.5	Advanced	41
6	COMMISSIONING FOR ENTRY INTO SERVICE	41
7	TROUBLESHOOTING	41
7.1	SELF-DIAGNOSIS	41
7.2	SELF-DIAGNOSIS OF INTERNAL FAULT	43
8	TECHNICAL DATA AND TYPE TESTS	44
8.1	TECHNICAL DATA	44
8.2	TYPE TESTS	45
9	SPECIFICATIONS FOR ORDERING	46



Illustrations

FIGURE 1 - SYSTEM TOPOLOGY.....	13
FIGURE 2 - EQUIPMENT TERMINAL.....	15
FIGURE 3 - BOTTOM AND REAR VIEW	16
FIGURE 4 - FRONT AND SIDE VIEW	16
FIGURE 5 - FRAME FOR PANEL MOUNTING.....	17
FIGURE 6 - WIRING DIAGRAM	20
FIGURE 7 - CONNECTION AND GROUNDING OF THE RS-485 SERIAL COMMUNICATION SHIELD	22
FIGURE 8 - CABLE AND GROUNDING CONNECTION DETAILS AND SHIELDING	23
FIGURE 9 - TAP ADAPTER MODEL 141	24
FIGURE 10 - CONNECTION AND GROUNDING DETAILS	25
FIGURE 11 - TAP ADAPTER SOCKET TERMINAL	25
FIGURE 12 - OPERATION VIA BM FRONT PANEL	26
FIGURE 13 - LOGIN SCREEN	27
FIGURE 14 - FILE TRANSFER SCREEN	27
FIGURE 15 - ABOUT SCREEN	27
FIGURE 16 - PARAMETERIZATION SECTION	28
FIGURE 17 - "APPLY" BUTTON	28
FIGURE 18 - DATE AND TIME SETTINGS	35



Tables

TABLE 1 - ENVIRONMENTAL CONDITIONS.....	8
TABLE 2 - CABLE SPECIFICATION	19
TABLE 3 - INPUTS	20
TABLE 4 - OUTPUTS	21
TABLE 5 - COMMUNICATION	21
TABLE 6 - SELF-DIAGNOSIS	42
TABLE 7 - SELF-DIAGNOSIS OF INTERNAL FAULT	43
TABLE 8 - TECHNICAL DATA	44
TABLE 9 - TYPE TESTS	45

1 Preface

1.1 Legal Information

The information contained in this document is subject to change without notice.

This document belongs to Treetech Tecnologia and may not be copied, transferred to third parties, or used without express authorization, in accordance with Law 9.610/98.

1.1.1 Disclaimer

Treetech Tecnologia reserves the right to make changes without prior notice to all products, circuits, and functionalities described herein in order to improve their reliability, function, or design. Treetech Tecnologia assumes no responsibility resulting from the application or use of any product or circuit described herein, nor does it transfer any licenses or patents under its rights, nor the rights of third parties.

Treetech Tecnologia may hold patents or other types of intellectual property registrations and rights described in the content of this document. Possession of this document by any person or entity does not grant them any rights to these patents or registrations.

1.2 Presentation

This manual presents all the recommendations and instructions for the installation, operation, and maintenance of the Bushing Monitor - BM.

1.3 Typographical conventions

Throughout this text, the following typographical conventions have been adopted:

Bold: Symbols, terms, and words in bold have greater contextual importance. Therefore, pay attention to these terms.

Italics: Foreign language terms, alternative terms, or terms used outside of formal contexts are italicized.

Underlined: References to external documents.

1.4 General and safety information

This section will present relevant aspects regarding the safety, installation, and maintenance of the BM.

1.4.1 Safety symbols

This manual uses three types of risk classification, as shown below:

**Warning:**

This symbol is used to highlight certain observations, alerting the user to a potentially dangerous operational or maintenance procedure that requires greater care in its execution. Minor to moderate injuries may occur, as well as damage to equipment.

**Caution:**

This symbol is used to alert the user to a potentially dangerous operational or maintenance procedure where extreme caution must be exercised. Serious injury or death may occur. Possible damage to equipment will be irreparable.

**Risk of electric shock:**

This symbol is used to alert the user to an operational or maintenance procedure that, if not strictly followed, could result in electric shock. Mild, moderate, or severe injury or death may occur.

1.4.2 General symbols

This manual uses the following general-purpose symbols:

**Important**

This symbol is used to highlight information.

**Tips**

This symbol represents instructions that facilitate the use of or access to functions in BM.

1.4.3 Minimum recommended profile for the BM operator and maintainer

The installation, maintenance, and operation of equipment in electrical substations require special care; therefore, all recommendations in this manual, applicable standards, safety procedures, safe work practices, and good judgment must be used during all stages of handling the Bushing Monitor - BM.



Only authorized and trained personnel, operators and maintenance staff, should handle this equipment.

To handle the BM, the professional must:

1. Be trained and authorized to operate, ground, start, and shut down the BM, following maintenance procedures in accordance with established safety practices, which are the sole responsibility of the BM operator and maintainer;
2. Being trained in the use of PPE (Personal Protective Equipment), CPE (Collective Protective Equipment), and first aid;
3. Being trained in the operating principles of the BM, as well as its configuration;
4. Follow the regulatory recommendations regarding interventions on any type of equipment within an electrical power system.

1.4.4 Environmental and voltage conditions required for installation and operation

The following table lists important information regarding environmental and voltage requirements.

Table 1 - Environmental conditions

Condition	Range/description
Supply voltage	85~250 Vac/Vdc
Application	Equipment for indoor use in substations, industrial environments and similar settings.
Indoor/outdoor use	Indoor use
Degree of protection (IEC 60529)	IP20
Altitude* (IEC EN 61010-1)	Up to 2000 m
Temperature (IEC EN 61010-1)	
Operation	-40...+85 °C
Storage	-50...+95 °C
Relative humidity (IEC EN 61010-1)	
Operation	5...90% - Non-condensing
Storage	5...90% - Non-condensing
Overvoltage (IEC EN 61010-1)	Category II
Pollution level (IEC EN 61010-1)	Degree 2
Atmospheric pressure** (IEC EN 61010-1)	80...110 kPa

* Altitudes above 2000 m already have successful applications.

** Pressures below 80 kPa already have successful applications.



1.4.5 Instructions for testing and installation

This manual should be available to those responsible for the installation, maintenance, and users of the Bushing Monitor - BM.

To ensure user safety, equipment protection, and proper operation, the following minimum precautions must be followed during the installation and maintenance of the BM.

1. Read this manual carefully before installing, operating, and maintaining the BM. Errors in the installation, maintenance, or adjustments of the BM may cause false alarms, failure to issue relevant alarms, and thus lead to a misunderstanding of the true health and operational status of the transformer or application, since the BM is designed to withstand electrical substation environments, also encompassing industrial and commercial environments.
2. The installation, adjustments, and operation of the BM must be performed by personnel trained and familiar with power transformers, control devices, and substation equipment control circuits, or who are familiar with and trained to implement the IED in its application.
3. Special attention should be given to the installation of the BM, including the type and gauge of the cables, the installation location and commissioning, including the correct parameterization of the equipment.



The BM must be installed in a sheltered environment (an open panel in a control room or an enclosed panel for outdoor installations) that does not exceed the temperature and humidity specified for the equipment.



Do not install the BM near heat sources such as heating resistors, incandescent lamps, and high-power devices or devices with heat sinks. Installation near ventilation openings or where it may be exposed to forced airflow, such as the inlet or outlet of cooling fans or forced ventilation ducts, is also not recommended.



If the panel where the BM is installed has a window, use a G20 or higher quality film to prevent direct sunlight (ultraviolet rays) from hitting the equipment. If the window glass is dark, this procedure is not necessary.



1.4.6 Instructions for cleaning and decontamination

Be careful when cleaning the BM. Use **only** a damp cloth with soap or detergent diluted in water to clean the housing, faceplate, or any other part of the equipment. Do not use abrasive materials, polishes, or harsh chemical solvents (such as alcohol or acetone) on any of its surfaces.



Turn off and unplug the equipment before cleaning any of its parts.

1.4.7 Instructions for inspection and maintenance

For inspection and maintenance of the BM, the following observations should be followed:



Do not open your equipment. There are no user-serviceable parts inside. This must be done by Treotech technical support or technicians accredited by them. This equipment is completely maintenance-free, and visual and operational inspections, periodic or not, can be performed by the user. These inspections are not mandatory.



All parts of this equipment must be supplied by Treotech, or one of its authorized suppliers, according to its specifications. If the user wishes to acquire them in another way, they must strictly follow Treotech's specifications for this. This will ensure that the performance and safety of both the user and the equipment are not compromised. Failure to follow these specifications may expose the user and the equipment to unforeseen risks.



Opening the BM at any time will void the product warranty. In cases of improper opening, Treotech will also be unable to guarantee its correct functioning, regardless of whether the warranty period has expired or not.



1.5 Customer Service

Are you already familiar with our online customer service platform?

[CS](#)

SAC



On the CS page, you'll find a quick and direct communication channel with our support team. Get your questions answered, resolve problems, and keep your Treotech product application up-to-date.

The Treotech knowledge base is also available, including catalogs, manuals, application notes, frequently asked questions, and more.



In some cases, it will be necessary to send the equipment to Treotech's Technical Assistance. Our Customer Service department will explain the entire procedure and provide the necessary contact information.



This manual accompanies firmware version 1.09r3



1.6 Warranty Terms

The Bushing Monitor - BM will be guaranteed by Treetech for a period of 2 (two) years, starting from the date of purchase, exclusively against any manufacturing defects or quality flaws that render it unsuitable for regular use.

The warranty will not cover damage to the product resulting from accidents, misuse, incorrect handling, incorrect installation and application, inadequate testing, or if the warranty seal is broken.

Any need for technical assistance should be communicated to Treetech or its authorized representative, presenting the equipment along with the corresponding proof of purchase.

Treetech provides no express or implied warranty other than those stated above. Treetech does not guarantee the suitability of BM for a particular application.

The seller shall not be liable for any property damage or for any losses or damages arising from, connected with, or resulting from the purchase of the equipment, its performance, or any service possibly provided in conjunction with the BM.

Under no circumstances shall the seller be liable for any losses incurred, including but not limited to: loss of profits or income, inability to use the BM or any associated equipment, capital costs, costs of purchased energy, costs of substitute equipment, installations or services, downtime costs, claims from the buyer's customers or employees, regardless of whether such damages, claims or losses are based on contract, warranty, negligence, tort or otherwise. Under no circumstances shall the seller be liable for any personal injury of any kind.

2 Introduction

2.1 Intended use




Figure 1 - System topology

Bushings are fundamental components in high-voltage equipment, being widely used in power transformers and shunt reactors. Their main function is to enable the passage of electric current between the external environment and the interior of the equipment, while simultaneously ensuring the necessary electrical insulation from the casing.

Due to this essential function, bushings are subject to high dielectric stresses, making any insulation failure a critical factor for the integrity of the equipment. A problem in this structure can result in severe damage and, in extreme situations, cause the total destruction of the equipment. In the case of power transformers, for example, the financial losses resulting from a dielectric failure can be hundreds of times greater than the cost of the bushing itself that caused the problem.

To mitigate these risks, the BM (Bushing Monitor) was developed, an advanced monitoring system capable of detecting variations in leakage current, tangent delta, and capacitance. This continuous monitoring allows for the identification of potential insulation failures at an early stage, contributing to the reliability and longevity of high-voltage equipment. It is performed in an integrated manner, analyzing all three bushings in the three-phase system. By comparing the measurements between them, the BM can detect even subtle changes, making the maintenance process safer, more efficient, and more reliable.



2.2 Features

✓ Robust hardware

The BM design meets EMC (Electromagnetic Compatibility) standards to withstand harsh electromagnetic conditions in substations and operating temperatures from -40 to 85°.

✓ Compact and versatile

The BM has compact dimensions, providing space savings and reduced installation costs.

2.3 Functions

✓ Monitoring sets

Monitoring of 3 bushings (one set).

✓ Alarms:

- Issuance of alarms in case of abnormalities, indicated by relays;
- Adjustable timing, allowing identification of rapidly or very rapidly evolving defects.

✓ Self-diagnosis

Detection of internal faults with indication from a relay.

✓ PT Monitoring

In addition to measuring current, the BM also measures voltage.

✓ Temperature measurement

The BM features a PT100 input, enabling temperature measurement for various applications.

✓ Trip relay

Trip relay activation via current alarms.

2.4 Inputs, outputs and communication

2.4.1 Inputs

- ✓ 1 current input set for a three-phase bushing set (primary or secondary);
- ✓ 1 set of three-phase voltage input;
- ✓ 1 PT100 sensor input.

2.4.2 Outputs

- ✓ 3 normally open (NO) output contacts for absolute value alarms;



- ✓ 1 fixed output contact (NC) for self-diagnosis.

2.4.3 Communication

BM has:

- ✓ 2 RS-485 ports for communication using Modbus/DNP3 RTU protocols;
- ✓ 1 Ethernet RJ45 port for **parameterization**.

3 Design and installation

3.1 Installation and removal of terminals

The terminals have screws to ensure a better fit, so care must be taken during installation and removal.

- ✓ Use a 2.5 mm flathead screwdriver;
- ✓ Before removing the terminals, check that the screws are completely loose;
- ✓ Forcing removal with the screws tightened may damage the BM.




Figure 2 - Equipment terminal

3.2 Mechanical installation

3.2.1 Standard DIN rail installation

This equipment is compatible with standard DIN rail mounting and can be located on mounting plates inside panels. It is important to ensure that the BM is securely attached to the rail; if there are no other IEDs nearby, the use of a rail lock is also recommended. After mounting, proceed with the electrical installation.




Figure 3 - Bottom and rear view





Figure 4 - Front and side view



3.2.2 Panel-mounted installation

The equipment can be installed recessed into panels, such as doors or front panels. It is important to observe the thickness of the panel's paint, as very thick layers can hinder insertion. It is also essential to ensure a firm fixation before carrying out the electrical installation. The dimensions of the equipment and the cutout required for mounting are presented below.



The panel cutout for IED mounting should be 91.1 x 121.5 mm

Figure 5 - Frame for panel mounting

3.3 Electrical installation

Some special precautions must be taken for the design and installation of the BM, as described below:



The connection terminals are installed on the top of the BM, in three removable connectors, to facilitate coupling. For information on cable gauges, see [Table 2](#)

—



Study and understand the application in which you intend to use the BM, learn about its functional, electrical, and configuration characteristics. This way you will be able to take full advantage of the equipment and minimize risks to your safety.



The following circuit breaker specification is recommended when used exclusively for BM:

- AC/DC Power Supply, Phase-Neutral: Single-pole circuit breaker, $1\text{ A} \leq I_n \leq 2\text{ A}$, curve B or C, standards NBR/IEC 60947-2, NBR/IEC 60898 or IEEE 3004.5;
- AC/DC Power Supply, Phase-to-Phase: Bipolar circuit breaker, $1\text{ A} \leq I_n \leq 2\text{ A}$, curve B or C, standards NBR/IEC 60947-2, NBR/IEC 60898 or IEEE 3004.5.



A circuit breaker should be used immediately before the power input (Universal power supply - $85 \sim 250\text{ V}_{dc}/\text{Vac}$, $<12\text{ W}$, $50/60\text{ Hz}$).

The circuit breaker must have the number of poles corresponding to the number of phases used in the power supply, and the poles must only interrupt the phases, never the neutral or ground. It must provide thermal and electrical protection to the conductors supplying the equipment and must be located near the equipment and easily maneuverable by the operator.

Additionally, it must have indelible markings indicating that it is the electrical disconnect device for the BM.



The minimum isolation for circuits connected to the BM is 300 V_{rms} for auxiliary equipment and transducers, such as Pt100 Ω at $0\text{ }^{\circ}\text{C}$, and up to 50 V_{rms} for self-powered equipment.

The minimum insulation is 1.7 kV_{rms} or equipment powered up to 300 V_{rms} , according to IEC 61010-1.

These values relate to the intrinsic isolation of devices connected to the BM. Cases where this value does not apply to equipment or devices connected to the BM will be explicitly stated in this manual.



3.3.1 Cable specification

Table 2 - Cable specification

Cable specification		
Function	Specification	Observation
Power supply GND	1.5mm ² to 2.5mm ²	-
TAP adapter	Exposed to the weather: Shielded cable (BTC), 2 x 18 AWG, EPR 90°C insulation, 0.6/1 kV. Protected from the weather: Shielded cable (BTC), 2 x 18 AWG, PVC insulation.	Mandatory, referring to NBR7286
Three-phase voltage signal	1.5mm ²	-
PT100	Exposed to the weather: 3x16 AWG cable with EPR insulation. Protected from the weather: 3x18AWG cable with PVC insulation.	This specification is mandatory and covers distances up to 265m. For greater distances, cables sized according to the installation requirements must be used. If you have any questions, contact the Treotech team; see Erro! Fonte de referência não encontrada..
Relays	1.5 mm²: Minimum gauge for signaling (self-diagnostics, alarms...). 2.5 mm²: Minimum gauge for power circuits (TRIP relay).	Recommended according to the specification in NBR5410.
RS485	Cabo 2x18AWG PVC	It is recommended to consult the Erro! Fonte de referência não encontrada. topic for installation.

3.3.2 Wiring diagram




Figure 6 - Wiring diagram

3.3.3 Input terminals

Table 3 - Inputs

Inputs	
Power supply Universal power input – 85 ~250 Vac/Vdc, 50/60Hz, 12 W.	01 – Vac/Vdc 02 – Vac/Vdc Ground
Three-phase voltage input This is a three-phase voltage input, where each of the three inputs corresponds to phases A, B, and C of a set of three-phase bushings. This input allows the measurement of amplitudes and phase shift angles between the phases.	19 – Phase A 20 – Phase B 21 – Phase C 22 – Neutral
Bushing set See .	23 – Signal input (Adapter A) 24 – Common input (Adapter A) 25 – Signal input (Adapter B) 26 – Common input (Adapter B) 27 – Signal input (Adapter C) 28 – Common input (Adapter C)
Input for PT100	17 – Common 16 – VM 18 – VR



Input for direct connection of a PT100 Ω sensor at 0 °C, in a three-wire measurement configuration.

3.3.4 Output terminals

Table 4 - Outputs

Outputs	
Signaling relays Relay (NO) with fixed function, relay 1 being for capacitance and relay 2 being for tangent delta.	09 – Relay 1 (NO) 10 – Common 11 – Relay 2 (NO)
Trip relay This relay (NO) has the function of switching off the transformer and is activated when an alarm is triggered by high or very high leakage current.	12 – Relay 3 (NO) 13 – Common
Self-diagnosis relay Relay (NC), signals internal faults, power supply issues, or problems with the connection cables.	14 – Relay 4 (NC) 15 – Common



The combined total current of all relays must not exceed 5 A.



The relays in the signaling group share the same common terminal. It is strictly forbidden to connect different phases or distinct power sources in the same group. All loads driven by this relay group must use the same phase and voltage reference.

3.3.5 Communication

Table 5 - Communication

Communication	
RS-485 (2)	03 – (-) 04 – (+) 07 – (-)

Connection to data acquisition system, Modbus RTU or DNP3 protocols, via shielded twisted-pair cable.	08 – (+)
RJ45 (Configuration) Configuration via HTTP, primarily used for equipment parameterization. This interface also allows for viewing measurements, as well as collecting and transmitting operational data.	1 Ethernet

Communication with the data acquisition system

Up to 31 devices can be interconnected on the same communication network. The communication protocols available for this connection are Modbus® and DNP3.

The connection between the BM and the data acquisition system must be made using a shielded twisted-pair cable, maintaining an uninterrupted shield throughout the entire length. If intermediate terminals are needed for serial communication, the cable shield should also pass through the terminal to avoid interrupting the connection.

In conjunction with the termination resistors, pull-up and pull-down resistors should be used at only one point in the network, as shown in Figure 7.

The 5V DC power supply for the pull-up and pull-down resistors can be internal to the data acquisition system. Note that some communication equipment may already have these resistors installed internally, eliminating the need for external resistors. The maximum distance of 1200 m between the ends of the communication network must be observed.




Figure 7 - Connection and grounding of the RS-485 serial communication shield

3.3.6 Temperature sensor

The BM has an input for a Pt100 Ω RTD temperature sensor at 0 °C. The sensor must be connected to the BM with shielded cables, maintaining a continuous shield and grounding

only at the end connected to the equipment. If intermediate terminals are used, the shielding must pass through them without interruption, and the unshielded sections should be as short as possible.

The maximum permissible resistance per path is $3\ \Omega$ ($6\ \Omega$ for the total path between the PT100 and the BM). For a $1.5\ \text{mm}^2$ copper cable, this allows the sensor to be installed up to 265 m from the equipment. Different distances can be achieved with proper cable sizing. If you have any questions, please contact Treotech's CS Department, see [Erro! Fonte de referência não encontrada.](#)




Figure 8 - Cable and grounding connection details and shielding

3.4 TAP adapter



Figure 9 - TAP Adapter
Model 141

The TAP adapter is an essential accessory for the operation of the BM; it is responsible for establishing the electrical connection with the bushing's TAP and also ensures mechanical rigidity and sealing against weathering. This equipment has internal protection against overvoltages and overcurrents resulting from transient phenomena, and also has a safety system against accidental opening of the measuring circuit, the TAP opening protection. This protection directs the leakage current through a low-impedance path, allowing the system to continue operating indefinitely, although it is advisable to take immediate action.

3.4.1 Mechanical installation

Mechanical installation of the TAP adapter requires the transformer to be de-energized. Carefully remove the capacitive TAP cover and connect the adapter manually, without using tools, to avoid damage to the terminal. It is essential to secure it firmly, but without applying excessive force, and anchor the cables or conduits to nearby structures to reduce stress on the adapter.

3.4.2 Electrical installation

The electrical installation involves connecting the shielded cable between the TAP adapter and the equipment, ensuring effective grounding of the shielding at a single point. A continuity test must be performed on the contact pin to ensure the integrity of the ground connection, verifying the drainage of leakage currents through the common terminal. The entire process must follow electrical safety recommendations and Treotech installation specifications. To learn how to perform the continuity test, see the [TAP adapter installation procedure](#).

To ensure the cable's mechanical strength, the use of very small gauges is not recommended, in order to reduce the possibility of accidental opening of the bushing's TAP. Gauges of 18 AWG or 0.75 mm² are indicated. The shielding of the connecting cables between the TAP adapters and the BM should also pass through terminals, preventing their interruption.

The unshielded cable section, due to the splice, should be as short as possible, and the shielding should be grounded at only one end, preferably at the tap adapter.



CAUTION: Under no circumstances should the bushing tap remain open while the bushing is energized. Therefore, it is highly recommended that the cables from the tap adapters not be connected directly to the current inputs of the transformer, but that short-circuitable intermediate terminals (such as those used for current transformer circuits) be used. See Figure 10. This makes it possible to short-circuit the intermediate terminals and divert leakage currents, allowing the transformer to be taken out of operation even with the bushings energized.




Figure 10 - Connection and grounding details

3.4.3 Layout of the TAP adapter socket terminals

Terminal 1: Signal terminal, connected to the signal input of the BM, see [Erro! Fonte de referência não encontrada](#)



Terminals 2, 3 and ground: Connected to each other and to the common terminal of the BM, see [Erro! Fonte de referência não encontrada](#)

Figure 11 - TAP adapter socket terminal

4 Operation

The equipment does not have a display or physical keys on its front panel for navigation; the only operation that can be performed directly on the front panel is changing the serial communication parameters using the “Default Address” button. Status, alarm, and internal fault signaling is provided by indicator lights (LEDs). The BM also features a user-friendly and intuitive web interface, through which it is possible to configure the equipment, download logs, and download databases.





Figure 12 - Operation via BM front panel

4.1 General information about the Web Interface

The web interface of the Bushing Monitor - BM allows access to all the equipment's functionalities. Through it, you can access the tabs: Online, File Transfer, Parameterization (only after logging in) and About, where information about measurements, product versioning information, log download, among others, is available.

4.1.1 Login



The login screen features the Treetech logo at the top. Below it, there is a dropdown menu labeled 'User' and a password input field with a toggle icon. A 'Recovery Code: 4210' is displayed below the password field. At the bottom, there is a green 'Enter' button.

In order to promote greater security, to access the BM parameterization tab, it is necessary to log in with your username and password.

For first access:

Profile: User


Password: 0

Afterwards, it can be changed by the user; a password will be displayed above the "Enter" field.

Figure 13 - Login screen

4.1.2 File transfer

Downloads the mass log; clicking opens a window that allows you to download the entire most recent log or a custom amount.



The 'Mass Log Download' dialog shows options to 'Reset', 'Full', or 'Manual'. It includes a 'Number of Records' field set to 50 and a 'Download the Most Recent Log' button. Below, it displays 'Total Available: 1813 Logs' and a date range from 2025/05/01 to 2025/05/01. A 'Download CSV' button is at the bottom.

Current Parameters File

Import JSON

Export JSON

It allows importing or exporting parameters and transfer them from one (new) BM to another, thus preserving the settings made by the user.

Logs


Mass Log

It allows importing or exporting the measurements made by the BM, both those that were used as a reference and the ongoing measurements.

Banks

Import Banks

Export Banks



The 'Bank Data' dialog shows a 'Select which file you want to export' section with 'Reference Bank' (Recent calibration data) and 'Monitoring Bank' (Speed reading history). A 'Download CSV' button is at the bottom.

Figure 14 - File transfer screen

4.1.3 About

BM2 - Bushing Monitoring	
Equipment information	
Functionality Version:	v1.08 r1
Bootloader Version:	v1.01 r4
Map Version:	10
Serial Number:	123123
Mac Address:	14:1A:51:00:00:00
IP address:	192.168.17.87
Network Mask:	255.255.255.0
Default Gateway:	192.168.87.1
DNS server:	8.8.8.8

The "about" page contains useful information for the efficient use of the product, such as:

- ✓ IP address;
- ✓ Firmware versions;
- ✓ Protocol map version.

Figure 15 - About screen



5 Parameterization

To ensure the correct operation of the system, the Bushing Monitor (BM) requires parameter adjustments, which provide the necessary information for its proper functioning and continuous monitoring. All adjustments and configurations are performed exclusively through its web interface; to access it, follow these steps:

- ✓ Connect the BM to the network via the parameterization port;
- ✓ Log in (the parameterization screen will only appear after logging in);
- ✓ When typing the device's IP address into any browser, it's important to verify that the device used for access is connected to the same network as the BM.

For the first access to the web interface, use the default IP address: **192.168.87.87**.




Figure 16 - Parameterization section

5.1 Inputting and validating parameters

Inputting parameters

For a parameter change to take effect in BM, you must click the "Apply" button after making the modifications. Changes made in the parameterization screens are stored temporarily and only become effective after clicking the "Apply" button.



Figure 17 - "Apply" button

5.2 Acquisition and analysis

5.2.1 Sampling settings

Sample interval between banks

Defines the interval for inserting samples into the banks.

Adjustment range: 5 to 2700 s

Default: 233 s

Number of samples considered for capacitance

Parameter that allows the definition of the number of samples for capacitance calculation.

Adjustment range: 10 to 5000

Default: 2600

Number of samples considered for tangent delta



Parameter that allows the definition of the number of samples for calculating the tangent delta.

Adjustment range: 10 to 5000

Default: 2600

Parameter to stop recording samples

Interrupts the insertion of samples into the banks.

Adjustment range: YES or NO

Default: NO

5.2.2 Initial phase parameters

Parameter for initial capacitance of phase 'x'

Initial capacitance value.

Adjustment range: 50 to 3200 pF

Default: 500 pF

Parameter for initial tangent delta of phase 'x'

Initial tangent delta value.

Adjustment range: 0.01 to 32.000 %F

Default: 0.3%

5.2.3 Adjustment parameters of the relevance curve

Relevance curve XA adjustment

Adjustment range: 0.000 to 5.000 %

Default: 0.450 %

Relevance curve XB adjustment

Adjustment range: 0.000 to 5.000 %

Default: 0.750%

Relevance curve YA adjustment

Adjustment range: 0.000 to 5.000 %

Default: 0.150% pF

Maximum percentage difference between redundant calculations

Adjustment range: 0 to 100 %

Default: 10%

Compensation activation

Adjustment range: ON or OFF

Default: OFF



5.2.4 Self-diagnosis

5.2.4.1 Validation and quality

Parameter for maximum percentage of corrupted samples in the banks

Indicates the maximum percentage of samples with errors that can be accepted, calculated based on the total number of samples stored in the banks.

Adjustment range: 0 to 100 %

Default: 5 %

Parameter for maximum persistent offset in the sample to be saved in the banks

This parameter defines the maximum allowed limit for the DC component present in the monitored signals; it should have tighter thresholds than the maximum DC value parameter for currents. See [Erro! Fonte de referência não encontrada..](#)

Adjustment range: 0 to 65000 μ A

Default: 50 μ A

Parameter for maximum angular distortion compared to the phase sequence of the first sample

This parameter defines the maximum acceptable angular displacement between phases, taking as a reference the phase sequence recorded in the first sample of the reference bank.

Adjustment range: 0 to 360°

Default: 5°

5.2.4.2 Frequency and signals

Parameter for maximum deviation from nominal frequency

This parameter defines the maximum permissible deviation from the nominal frequency of the electrical system.

Adjustment range: 0.000 to 1.000 Hz

Default: 0.300 Hz

Parameter for maximum difference between frequencies in the same group of signals

This parameter defines the maximum allowed difference between the frequencies of the monitored signals in the same sample.

Adjustment range: 0.000 to 1.000 Hz

Default: 0.100 Hz

Parameter for minimum current amplitude in the fundamental

This parameter defines the minimum amplitude in the fundamental component of the current for the self-diagnosis to be triggered.

Adjustment range: 100 to 65000 μ A

Default: 100 μ A

Parameter for minimum voltage amplitude in the fundamental

This parameter defines the minimum amplitude in the fundamental voltage component for the self-diagnosis to be triggered.

Adjustment range: 1 to 65000 V



Default: 1 V

Parameter for maximum DC value in currents

This parameter defines the maximum allowed limit for the DC component present in the monitored current signals.

Adjustment range: 0 to 65000 μ A

Default: 100 μ A

Parameter for maximum DC value in voltages

This parameter defines the maximum allowed limit for the DC component present in the monitored voltage signals.

Adjustment range: 0 to 65000 V

Default: 1 V

Parameter for maximum harmonic distortion relative to the True RMS value

This parameter defines the maximum allowed limit for total harmonic distortion (THD) relative to the True RMS value of the signal.

Adjustment range: 0.0 to 100.0 %

Default: 20.0 %

5.2.4.3 Summation ratio

Parameter for current of dead zone of inconsistent summation self-diagnosis

This parameter defines the dead zone, which is the minimum RMS amplitude value required to enable self-diagnosis.

Adjustment range: 0 to 2000 μ A

Default: 10 μ A

Parameter for maximum ratio for consistency of summations

This parameter defines the value that, when reached, triggers the self-diagnosis. This value is the difference between the sums.

Adjustment range: 0 to 200 %

Default: 50 %

Note: The self-diagnosis of inconsistent summation will only be triggered when the range of any summation (measured or calculated) exceeds the dead zone and the difference between them exceeds the configured percentage.

5.2.4.4 Voltage monitoring

Parameter to enable voltage signal monitoring

Adjustment range: Enable or Disable

Default: Enable

5.2.5 PT100 sensor configuration

Parameter to enable PT100 sensor

Adjustment range: Enable or Disable

Default: Disable



Parameter to enable PT100 sensor simulation

Adjustment range: Enable or Disable

Default: Disable

5.3 Communication

5.3.1 Serial communication ports (RS485 - 'X')

Baudrate – User serial number 'x'

Selects the baud rate for the RS-485 serial communication port.

Adjustment range: 4800 / 9600 / 19200 / 38400 / 57600 / 115200 bps

Default: 9600 bps

Active protocol – User serial number 'x'

Selects the standard protocol to be used for communication with data acquisition systems..

Adjustment range: Modbus or DNP3

Default: Modbus

RS485 Network address – Serial

Defines the BM address on the RS-485 communication port, for communication with data acquisition systems.

Adjustment range: 1 to 65519

Default: 247

Delay in reception – User serial number 'x'

This parameter defines the data reception wait time; in other words, it's the wait time for receiving a data packet.

Adjustment range: 5 to 500 ms

Default: 5 ms

Transmission delay – User serial number 'x'

This parameter defines the data transmission wait time; in other words, it's the wait time between one transmission and another.

Adjustment range: 5 to 500 ms

Default: 25 ms

5.3.2 Confirmation key

Parameter for confirmation key to apply serial parameterization

To apply the serial parameter settings, it is necessary to confirm the operation using the confirmation key. This key is only required for protocol changes, ensuring greater security.

Adjustment range: 0 to 65535

Default: 0

Unlock value: 43605



Parameter for confirmation key to apply IP address parameterization

To apply the IP address parameter settings, you must confirm the operation using the confirmation key. This key is only required for protocol changes, ensuring greater security.

Adjustment range: 0 to 65535

Default: 0

Fixed value: 43605

5.3.3 Network

5.3.3.1 Parameter for IP address

It defines the device's IP address on the network, allowing it to be identified and communicate with other devices.

Parameter for IP address – byte 0

Adjustment range: 0 to 255

Default: 192

Parameter for IP address – byte 1

Adjustment range: 0 to 255

Default: 168

Parameter for IP address – byte 2

Adjustment range: 0 to 255

Default: 87

Parameter for IP address – byte 3

Adjustment range: 0 to 255

Default: 87

5.3.3.2 Parameter for network mask

Configures the subnet mask, determining the range of IP addresses available for communication.

Parameter for network mask – byte 0

Adjustment range: 0 to 255

Default: 255

Parameter for network mask – byte 1

Adjustment range: 0 to 255

Default: 255

Parameter for network mask – byte 2

Adjustment range: 0 to 255

Default: 255



Parameter for network mask – byte 3

Adjustment range: 0 to 255

Default: 0

5.3.3.3 Parameter for gateway address

Specifies the address of the default gateway, responsible for forwarding packets to external networks.

Parameter for default gateway address – byte 0

Adjustment range: 0 to 255

Default: 192

Parameter for default gateway address – byte 1

Adjustment range: 0 to 255

Default: 168

Parameter for default gateway address – byte 2

Adjustment range: 0 to 255

Default: 87

Parameter for default gateway address – byte 3

Adjustment range: 0 to 255

Default: 1

5.3.3.4 Parameter for DNS server address

Defines the DNS server address, used to translate domain names into IP addresses.

Parameter for DNS server address – byte 0

Adjustment range: 0 to 255

Default: 8

Parameter for DNS server address – byte 1

Adjustment range: 0 to 255

Default: 8

Parameter for DNS server address – byte 2

Adjustment range: 0 to 255

Default: 8

Parameter for DNS server address – byte 3

Adjustment range: 0 to 255

Default: 8



5.4 System and control

Allows date and time settings in UTC format.

Figure 18 - Date and time settings

5.4.1 Manually setting the date and time

UTC Time – Year

Adjusts the year.

Adjustment range: 1970 to 65535

Default: 2025

UTC Time – Month

Adjusts the month.

Adjustment range: 1 to 12

Default: 1

UTC Time – Day

Adjusts the day.

Adjustment range: 1 to 31

Default: 1

UTC Time – Hour

Adjusts the hour.

Adjustment range: 0 to 23 h

Default: 0 h

UTC Time – Minutes

Adjusts the minutes.

Adjustment range: 0 to 59 m

Default: 0 m

UTC Time – Seconds

Adjusts the seconds.

Adjustment range: 0 to 59 s

Default: 0 s



5.4.2 Time zone

Sets the time zone offset relative to UTC.

Time zone – Hours

Adjusts the time zone in hours.

Adjustment range: -24 to 24

Default: -3

Time zone – Minutes

Adjusts the time zone in minutes.

Adjustment range: 0 to 59

Default: 0

5.4.3 Mass log interval

Parameter for time interval for saving the mass log

Defines the interval for periodic saving of the mass log.

Adjustment range: 1 to 9999 min

Default: 60 min

5.5 Alarms

5.5.1 Automatic mode activation

Parameter to enable automatic mode for the alarms due to leakage current

Enables automatic alarms for leakage current.

Adjustment range: YES or NO

Default: YES

Parameter to enable automatic mode for the alarms due to capacitance

Enables automatic alarms for capacitance.

Adjustment range: YES or NO

Default: YES

Parameter to enable automatic mode for the alarms due to tangent delta

Enables automatic alarms for tangent delta.

Adjustment range: YES or NO

Default: YES

5.5.2 General settings

Alarm hysteresis

Adjustment range: 0 to 100%

Default: 5%

Parameter to enable current TRIP

Adjustment range: YES or NO

Default: YES



5.5.3 Percentages for automatic alarms

The **automatic alarm due to leakage current** is based on the average value obtained during the reference process. The configured percentage is applied to this average value.

Parameter of percentage for automatic alarm due to high leakage current

Adjustment range: 0 to 100 %

Default: 10%

Note: For this parameter to be displayed, the automatic mode for alarms due to leakage current must be enabled.

Parameter of percentage for automatic alarm due to very high leakage current

Adjustment range: 0 to 100 %

Default: 20%

Note: For this parameter to be displayed, the automatic mode for alarms due to leakage current must be enabled.

The automatic alarms related to **capacitance and tangent delta** are adjusted as percentage increases relative to their initial values. Initial values must be programmed before using automatic mode.

Parameter of percentage for automatic alarm due to high capacitance

Adjustment range: 0 to 100 %

Default: 10%

Note: For this parameter to be displayed, the automatic mode for alarms due to capacitance must be enabled.

Parameter of percentage for automatic alarm due to very high capacitance

Adjustment range: 0 to 100 %

Default: 20%

Note: For this parameter to be displayed, the automatic mode for alarms due to capacitance must be enabled.

Parameter of percentage for automatic alarm due to high tangent delta

Adjustment range: 0 to 100 %

Default: 10%

Note: For this parameter to be displayed, the automatic mode for alarms due to tangent delta must be enabled.

Parameter of percentage for automatic alarm due to very high tangent delta

Adjustment range: 0 to 100 %

Default: 20%

Note: For this parameter to be displayed, the automatic mode for alarms due to tangent delta must be enabled.



5.5.4 Alarm timing

Parameter of timing for alarm due to high leakage current

Sets the delay time for the alarm to be triggered.

Adjustment range: 0 to 3600 s

Default: 60 s

Parameter of timing for alarm due to very high leakage current

Sets the delay time for the alarm to be triggered.

Adjustment range: 0 to 3600 s

Default: 30 s

The following settings will only be displayed if the “**Parameter to enable current TRIP**” is enabled.

Parameter of timing for tripping due to high leakage current

Sets the delay time for the TRIP relay to activate upon the alarm due to high leakage current.

Adjustment range: 0 to 3600 s

Default: 75 s

Parameter of timing for tripping due to very high leakage current

Sets the delay time for the TRIP relay to activate upon the alarm due to very high leakage current.

Adjustment range: 0 to 3600 s

Default: 45 s

5.5.5 Manual thresholds

These parameters will only be displayed if the respective alarms are not configured in automatic mode.

5.5.5.1 Leakage current – High

Manual threshold parameter for high leakage current – phase ‘x’

Selection of desired values for the emission of the alarm due to high leakage current.

Adjustment range: 0.20 to 650.00mA

Default: 80 mA

5.5.5.2 Leakage current – Very high

Manual threshold parameter for very high leakage current – phase ‘x’

Selection of desired values for the emission of the alarm due to very high leakage current.

Adjustment range: 0.20 to 650.00 mA

Default: 90 mA

5.5.5.3 Capacitance – High

Manual threshold parameter for high capacitance – phase ‘x’

Selection of desired values for the emission of the alarm due to high capacitance.



Adjustment range: 50.0 to 6500.0 pF

Default: 515 pF

5.5.5.4 Capacitance – Very high

Manual threshold parameter for very high capacitance – phase 'x'

Selection of desired values for the emission of the alarm due to very high capacitance.

Adjustment range: 50.0 to 6500.0 pF

Default: 525 pF

5.5.5.5 Tangent delta – High

Manual threshold parameter for high tangent delta – phase 'x'

Selection of desired values for the emission of the alarm due to high tangent delta.

Adjustment range: 0.010 to 65.000 %

Default: 0.7 %

5.5.5.6 Tangent delta – Very high

Manual threshold parameter for very high tangent delta – phase 'x'

Selection of desired values for the emission of the alarm due to very high tangent delta.

Adjustment range: 0.010 to 65.000 %

Default: 1.05 %

5.5.6 Trend-based alarms

Estimated minimum time for alarm due to high capacitance - phase A/B/C (days):

Defines a minimum time for triggering trend alarms due to high capacitance in phases A, B, or C.

Adjustment range: 1 to 365 days

Default: 30 days

Estimated minimum time for alarm due to very high capacitance - phase A/B/C (days):

Defines a minimum time for triggering trend alarms due to very high capacitance in phases A, B, or C.

Adjustment range: 1 to 365 days

Default: 30 days

Estimated minimum time for alarm due to high tangent delta - phase A/B/C (days):

Defines a minimum time for triggering trend alarms due to high tangent delta in phases A, B, or C.

Adjustment range: 1 to 365 days

Default: 30 days

Estimated minimum time for alarm due to very high tangent delta - phase A/B/C (days):

Defines a minimum time for triggering trend alarms due to very high tangent delta in phases A, B, or C.



Adjustment range: 1 to 365 days

Default: 30 days

5.6 Commands

5.6.1 Control and monitoring of banks

Command to reset reference bank

Adjustment range: YES or NO

Default: NO

Command to restart monitoring bank

Adjustment range: YES or NO

Default: NO

5.6.2 Maintenance and cleaning

Command to clear alarm memory

Adjustment range: YES or NO

Default: NO

Command to clear self-diagnosis memory

Adjustment range: YES or NO

Default: NO

Command to reset maximum temperature

Adjustment range: YES or NO

Default: NO

Command to clear temperature jump

Adjustment range: YES or NO

Default: NO

5.6.3 Resetting trend calculations

Command to reset capacitance trend calculations in phase A/B/C

Adjustment range: YES or NO

Default: NO

Command to reset tangent delta trend calculations in phase A/B/C

Adjustment range: YES or NO

Default: NO

5.6.4 Resetting communication settings

Command to reset network parameters to default values



Adjustment range: YES or NO
Default: NO

Command to reset serial parameters to default values

Adjustment range: YES or NO
Default: NO

5.6.5 Advanced

Command to reset user parameters to default values

Adjustment range: YES or NO
Default: NO

Command to reset the mass log

Adjustment range: YES or NO
Default: NO

6 Commissioning for entry into service

Once the equipment has been installed in accordance with this manual, commissioning should follow the basic steps below.

- ✓ Verify the electrical installation according to the recommendations in this manual. Check the correctness of the electrical connections (for example, through continuity tests);
- ✓ Ensure that no contact operations will interact with other systems during this phase. If necessary, isolate all control, alarm, and shutdown contacts;
- ✓ Perform all BM parameterization according to the instructions in this manual;
- ✓ Reconnect any contacts that may have been isolated;
- ✓ After installation, it is important to check the operation of the LEDs, especially the equipment status via its respective LED (see [Operation](#)).

7 Troubleshooting

7.1 Self-diagnosis

The following table contains recommended solutions for self-diagnoses. If the warning persists or reappears after some time, contact Treotech technical support (see [Erro! Fonte de referência não encontrada.](#)).

Table 6 - Self-diagnosis

Self-diagnosis	Recommendation
Self-diagnosis of phase sequence	Check the installation; this self-diagnosis indicates that there may be a phase reversal, meaning the cables may be reversed.
Self-diagnosis of channel current with high frequency difference	Check the installation; it may also indicate an internal fault.
Self-diagnosis of channel current with low leakage current	Check the installation; this self-diagnosis indicates that there may be an error in the installation or loose cables.
Self-diagnosis of channel voltage with low voltage	Check the installation; this self-diagnosis indicates that there may be an error in the installation or loose cables.
Self-diagnosis of persistent offset in the sample bank	Check the TAP adapter; the display of this self-diagnosis may indicate a fault in the TAP adapter.
Self-diagnosis of channel current with offset outside limits	Check the TAP adapter; the display of this self-diagnosis may indicate a fault in the TAP adapter.
Self-diagnosis of calculated current summation with high frequency difference	Check the installation; it may also indicate an internal fault.
Self-diagnosis of calculated current summation with offset outside limits	Check the TAP adapter; the display of this self-diagnosis may indicate a fault in the TAP adapter.
Self-diagnosis of measured current summation with high frequency difference	Check the installation; it may also indicate an internal fault.
Self-diagnosis of measured current summation with offset outside limits	Check the TAP adapter; the display of this self-diagnosis may indicate a fault in the TAP adapter.
Self-diagnosis of frequency discrepancy	Check the installation; it may also indicate an internal fault.
Self-diagnosis of total harmonic distortion	Check the installation; it may also indicate an internal fault.
Self-diagnosis of PT100 calibration	a) Check for poor connections or disconnections throughout the entire



Self-diagnosis of PT100 reading	cable path connected to terminals 1 and 2 of the temperature sensor, including the connection to the BM, the feed-through terminals, and the connection to the sensor. b) Check if shielded cable is being used to connect the temperature sensor to the BM. c) Verify that the shielding of the temperature sensor cable is grounded only on one side of the connection and the other end is insulated. d) Replace the faulty temperature sensor.
Self-diagnosis of PT100 cable reading	
Self-diagnosis of temperature jump	
Self-diagnosis of overflow in PT100 readings	

7.2 Self-diagnosis of internal fault

If any of the self-diagnosis issues listed below occur, it is necessary to reset the BM. This can be done by removing and reconnecting the power supply. If the self-diagnosis issue persists or recurs after some time, it is recommended to contact Treotech technical support (see [Erro! Fonte de referência não encontrada.](#)) for analysis and appropriate guidance.

Table 7 - Self-diagnosis of internal fault

Internal fault
Self-diagnosis of general inaccuracy in phase angles
Self-diagnosis of inconsistency in the summation
Self-diagnosis of measurement failure in the current assembly
Self-diagnosis of measurement failure in the voltage assembly
Self-diagnosis of channel current with indeterminate waveform
Self-diagnosis of channel current near ADC saturation
Self-diagnosis of channel current with angular inaccuracy
Self-diagnosis of calculated current summation with indeterminate waveform
Self-diagnosis of calculated current summation near ADC saturation
Self-diagnosis of calculated current summation with angular inaccuracy
Self-diagnosis of measured current summation with indeterminate waveform
Self-diagnosis of measured current summation near ADC saturation
Self-diagnosis of measured current summation with angular inaccuracy
Self-diagnosis of error in the PT100 sensor calibration circuit
Self-diagnosis of error in internal flash memory
Self-diagnosis of error in external flash memory
Self-diagnosis of error in the internal temperature sensor on the board
Self-diagnosis of errors in the clock's RTC circuit
Self-diagnosis in the TRIP relay circuit (safe activation)
Self-diagnosis of channel tension with indeterminate waveform



Self-diagnosis of channel voltage near ADC saturation
Self-diagnosis of channel tension with angular inaccuracy
Self-diagnosis of low statistical performance
Self-diagnosis of many corrupted samples in the bank

8 Technical data and type tests

8.1 Technical data

Table 8 - Technical data

HARDWARE	
Supply voltage	85...250 Vac/Vdc
Frequency	50/60 Hz
Maximum consumption	<12 W
Operating temperature	-40...85 °C
Degree of protection	IP20
Fixation	Panel DIN rail
INPUTS	
Current inputs (1 set)	0...100 mA
Three-phase voltage inputs (1 set)	0...185 Vac
1 RTD	PT100 Ω at 0°C with 3 wires, range -55...200°C
OUTPUTS	
1x Self-diagnosis relay	Normally Closed (NC) Contact Dielectric strength: 4000Vrms 3 A at 125 VAC (NC) 3 A at 250 VAC (NC) 3 A at 30 VDC (NC)
1x TRIP Relay	Normally Open (NO) Contact Dielectric strength: 4000Vac 5 A at 125 VAC (NO) 5 A at 250 VAC (NO) 5 A at 30 VDC (NO)
2x Signaling relays	Normally Open (NO) Contacts Dielectric strength: 4000Vac 5 A at 125 VAC (NO) 5 A at 250 VAC (NO) 5 A at 30 VDC (NO)



The current carrying capacity of the common terminal is 5A. Therefore, if multiple relays are used simultaneously, the sum of their currents must respect this limit to avoid overload and overheating of the connection.

COMMUNICATION INTERFACE

Communication protocols	DNP3 Modbus® RTU
Communication ports	2 RS-485
Configuration port	1 RJ45

DIMENSIONS AND WEIGHT

DESCRIPTION

Dimensions	146.8 mm x 131.1 mm x 90 mm
Weight	Approx. 1000g

8.2 Type tests

Table 9 - Type tests

IMMUNITY TO HIGH-ENERGY SURGES (IEC 60255-26:2023)	
Differential mode	2 kV (+/-)
Common mode	4 kV (+/-)
IMMUNITY TO ELECTRICAL TRANSIENTS (1 MHz BURST, IEC 60255-26:2023)	
Peak value 1st cycle	2.5 kV (common mode), 1 kV (dif. mode)
Frequency	1 MHz
Repetition rate	200 bursts/s
APPLIED VOLTAGE (IEC 60255-26:2023)	
Dielectric strength	2 kV at 60 Hz for 1 minute
Voltage impulse	5 kV (+/-)
IMMUNITY TO RADIATED ELECTROMAGNETIC FIELDS (IEC 60255-26:2023)	
Frequency	80...2500 Mhz
Modulation index	80% and 1 kHz sinusoidal
Field intensity	10 V/m
Power supply	220 V / 60 Hz
IMMUNITY TO CONDUCTED ELECTROMAGNETIC DISTURBANCES (IEC 60255-26:2023)	
Field intensity	10 Vrms
Frequency	0.15 a 80 MHz
Modulation index	80% and 1 kHz sinusoidal
Scan frequency	150 kHz to 80 MHz
Fixed frequencies	27
Duration	20 s
Power supply	220 V / 60 Hz
IMMUNITY TO INDUSTRIAL FREQUENCY MAGNETIC FIELDS (IEC 61000-4-8)	
Magnetic field intensity and direction	30 A/m 3 orthogonal axes
ELECTROSTATIC DISCHARGES (IEC 60255-26:2023)	
Air discharge	15 kV
Contact discharge	220 V / 60 Hz
IMMUNITY TO FAST ELECTRICAL TRANSIENTS (IEC 60255-26:2023)	
Power, inputs and outputs (Class A)	4 kV (+/-)
Current output	2 kV (+/-)
CONDUCTED EMISSION (IEC 60255-26:2023)	



Conducted emission limits (Class A)	79 dB (uV) @ 150 kHz...500 kHz (QP) 73 dB (uV) @ 500 kHz...30 MHz (QP) 66 dB (uV) @ 150 kHz...500 kHz (AV) 60 dB (uV) @ 500 kHz...30 MHz (AV)
RADIATED EMISSION (IEC 60255-25)	
Radiated emission limits (Class B)	50 dB (uV/m) @ 30 MHz...230 MHz (QP) 57 dB (uV/m) @ 230 MHz...1 GHz (QP)
POWER FAILURE (IEC 61000-4-11)	
Amplitude variation	0...80% amplitude
Affected cycles	1/2...300 cycles
Power supply	85 V...265 V - 50/60 Hz
Short interruptions	5 seconds 85 V and 265 V 50/60 Hz
COLD TOLERANCE (IEC 60068-2-1)	
Temperature	-40°C
Test time	16 hours
DRY HEAT TOLERANCE (IEC 60068-2-2)	
Temperature	+85 °C
Test time	16 hours
HUMID HEAT TOLERANCE (IEC 60068-2-78)	
Temperature and relative humidity	+40 °C...85% UR
Test time	24 hours
THERMAL CYCLE (IEC 60068-2-14)	
Temperature range	-40...85 °C
Total test time	120 hours
RESPONSE TO VIBRATION (IEC 60255-21-1)	
Application mode	Sinusoidal
Amplitude and frequency range	0.075 mm (10...59 Hz) 1 G (59...150 Hz)
Duration	8 min/eixo
VIBRATION DURABILITY (IEC 60255-21-1)	
Application mode	Senoidal
Amplitude and frequency range	2G (10...150 Hz)
Duration	160 min/axis

9 Specifications for ordering

In the product purchase order, it is necessary to specify:

- ✓ Product name;
- ✓ Quantity;
- ✓ Accessories.





Treotech®

Treotech Tecnologia

Rua José Alvim, 112, Centro

Cep 12940-750 – Atibaia/SP

+55 11 2410 1190

www.treotech.com.br